

DREAM 6012 WASH 通道特性表

Mod1	Mod2	Mod3	Mod4	特性	DMX值	功能
1	1	1	1	水平	0-255	0度->540度
2	2	2	2	水平微调		
3	3	3	3	垂直	0-255	0度->252度
4	4	4	4	垂直微调		
5	5	5	5	频闪	0-19	关闭
					20-49	打开
					50-200	频闪, 慢->快
					201-210	开
					211-255	随机频闪, 慢->快
-	6	6	6	调光	0-255	0%->100% 关->开
-	-	7	-	调光微调		
6	7	8	7	放大缩小	0-255	小->大
-	-	9	-	放大缩小微调		
-	8	10	-	红色	0-255	0%->100%
-	-	11	-	红色微调		
-	9	12	-	绿色	0-255	0%->100%
-	-	13	-	绿色微调		
-	10	14	-	蓝色	0-255	0%->100%
-	-	15	-	蓝色微调		
-	11	16	-	白光	0-255	0%->100%
-	-	17	-	白光微调		
7	-	-	-	色调(Hue)	0-255	0-360
8	-	-	-	色调(Hue Fine)		
9	-	-	-	饱和度(S)	0-255	0%->100%
10	-	-	-	亮度(I)	0-255	0%->100%
11	12	18	-	色温CT0	0-15	无功能
					16-255	8000K-2500K
-	13	19	-	颜色宏	0-9	0%->100%
					10-204	数值每隔3一种宏
					205-255	保留
12	14	20	-	点阵效果	0-9	无功能
					10-11	效果1
					12-13	效果2
					14-15	效果3
					16-17	效果4
					18-19	效果5
					20-201	效果6
					22-23	效果7
					24-25	效果8
					26-27	效果9
					28-29	效果10
					30-31	效果11
					32-33	效果12
					34-35	效果13
					36-37	效果14
					38-39	效果15
					40-41	效果16
					42-43	效果17
					44-45	效果18
					46-47	效果19
					48-49	效果20
					50-51	效果21
					52-53	效果22
					旋转图形	
					54-57	效果1
					58-62	效果2
					59-58	效果3
					58-63	效果4
					54-59	效果5
					58-64	效果6
					54-60	效果7
					58-65	效果8
					54-61	效果9
					58-62	效果10
					63-67	效果11
					68-71	效果12
					72-75	效果13
					76-79	效果14
					80-83	效果15
					84-87	效果16
					88-89	效果17
					90-93	效果18
					94-97	效果19
					98-101	效果20
					102-105	效果21
					106-109	效果22
					110-113	效果23
114-117	效果24					
118-121	效果25					
122-125	效果26					
126-129	效果27					
130-133	效果28					
134-255	固定颜色效果					
13	15	21	-	点阵效果速度	0-255	点阵速度从慢到快
14	16	22	8	灯具控制	0-15	无
					16-25	P/T/Z reset
					26-35	Curve1 Choose
					36-45	Curve2 Choose
					46-55	Curve3 Choose
					56-65	Curve4 Choose
					66-75	Fan Auto
					76-85	Fan Silent
					86-90	Block Mode Open
					96-105	Block Mode Closed
					106-75	仿卤素灯打开
					116-85	色温3200
					126-90	色温5600
					136-105	色温6500
146-155	色温8000					
156-255	保留					
-	17	23	9	水平垂直速度	0-255	滑步时间从快到慢
-	-	-	10-13	红色1~白色1	0-255	0%->100%
-	-	-	14-17	红色2~白色2	0-255	0%->100%
-	-	-	18-21	红色3~白色3	0-255	0%->100%
-	-	-	22-25	红色4~白色4	0-255	0%->100%
-	-	-	26-29	红色5~白色5	0-255	0%->100%
-	-	-	30-33	红色6~白色6	0-255	0%->100%
-	-	-	34-37	红色7~白色7	0-255	0%->100%
-	-	-	38-41	红色8~白色8	0-255	0%->100%
-	-	-	42-45	红色9~白色9	0-255	0%->100%
-	-	-	46-49	红色10~白色10	0-255	0%->100%
-	-	-	50-53	红色11~白色11	0-255	0%->100%
-	-	-	54-57	红色12~白色12	0-255	0%->100%